



Summit International Flooring

CLASS

CLEANING AND MAINTENANCE INSTRUCTIONS

Class “Leather” Rubber Tiles have been scientifically engineered to provide you with a beautiful yet low-maintenance product. Its polyurethane coating (PUR) along with its closed surface finish allows for a polish-free maintenance regime. The following instructions pertain to CLASS when installed as a floor covering. Please modify these directions accordingly when CLASS is applied to walls and other surfaces.

Initial Cleaning

- Remove all loose debris
- Ensure that all traces of adhesive are removed from the surface
- Sweep or vacuum to remove dust and grit
- Damp sponge (do not over wet) with a neutral detergent, such as Taski Neutral Cleaner

Routine Maintenance

The following recommendations are provided as a guideline and the frequency may be increased to optimize CLASS’s beauty and appearance:

- Daily and/or weekly, damp sponge, sweep or vacuum to remove dust and loose dirt
- If necessary, spot clean to remove stubborn marks with a neutral cleanser such as Taski Neutral Cleaner

Additional Notes:

- Cleaners and detergents should be diluted as per the manufacturers’ instructions. Always follow the Health and Safety guidelines provided
- These maintenance instructions are intended for the PUR range of floor coverings, which have a polyurethane reinforcement
- In most cases, the above maintenance regime will be sufficient to ensure your floor or other surface retains the optimum appearance
- Regular Cleaning is more beneficial to the surface or floor covering and more cost-effective than occasional heavy cleaning
- The use of any acid or phosphate based detergents are NOT recommended

It is imperative that you follow the Cleaning and Maintenance Instructions as directed. Summit International Flooring will NOT be held responsible for damage due to cleaning and maintenance of the tiles. For your own protection, we ask that you carefully inspect the material for any damage or deficiencies PRIOR TO installation. Keep in mind that certain lighting conditions, shadows and/or glare may alter the appearance of the material.

Please contact Summit International Flooring immediately if you are dissatisfied with the tiles upon first inspection. The material warranty is only in effect before ANY steps of the installation process have begun.

Please address and questions or comments to:

Summit International Flooring, P.O. Box 90, Livingston, NJ 07039 (877) 496-3566 www.summit-flooring.com

8/4/2010